# Yealink T46s Quick User Guide



#### Call Transfer

You can transfer a call in the following ways:

#### **Blind Transfer**

- 1. Press or tap the *Transfer* soft key during an active call. The call is placed on hold.
- 2. Enter the number you want to transfer to.
- 3. Press (4) or tap the *Transfer* soft key.

## **Attended Transfer**

- 1. Press (4) or tap the *Transfer* soft key during an active call. The call is placed on hold.
- 2. Enter the number you want to transfer to, and then press #....
- 3. Press or the *Transfer* soft key when the second party answers.

## Transfer Directly To Voicemail

Press # 99 followed by the 4 digit extension number and hang up the phone.

The call is directly send to the extension's voicemail.

## Call Conference

- 1. Tap the Conference soft key during an active call. The call is placed on hold.
- 2. Enter the number of the second party, and then press the **Send** soft key.
- 3. Tap the *Conference* soft key again when the second party answers.

  All parties are now joined in the call.
- 4. Tap the End Call soft key to disconnect all parties.

## **Call History**

- 1. Press the *History* soft key when the phone is idle.
- 2. Press (-) or (-), to scroll through the list.
- 3. Select an entry from the list. You can do the following:
  - Press Send soft key to call the entry.
  - Press **Delete** soft key to delete the entry from the list.

If you press the *Option* soft key, you can do the following:

- Select **Detail** to view detailed information about the local directory.
- Select Add to Contact to add the entry to the local directory.
- · Select Add to Blacklist to add the entry to the blacklist.
- · Select Delete All to delete all entrys from the list.

## Call Forward (Also can be set up in CommPortal)

To enable call forward:

- 1. Press the *Menu* soft key then press --> Features --> Call Forward.
- 2. Select the desired forward type:
  - · Always Forward: Incoming calls are forwarded on every call.
  - · Busy Forward: Incoming calls are only forwarded when the phone is busy.
  - · No Answer Forward: Incoming calls are only forwarded if not answered after a period of time.
- Enter the number you want to forward to. For No Answer Forward, press or to select the desired ring time to wait before forwarding from the After Ring Time field.
- 4. Press the Save soft key to accept the change.

Technical Support

www.atcnet.net/business-voice/business-support